

ErP Product Information

Product name: LTE CPE

Model: B535-333

Hereby, Soyea Technology Co., Ltd. declare under our sole responsibility that the above referenced product complies with the following directives and standards:

ErP Directive 2009/125/EC: (EC) No 1275/2008; (EU) No 801/2013; EN 50564:2011; (EU) No 617/2013; (EU) 2019/2021; (EU) 2019/1782

AS of 1 January 2015, the following information for network equipment shall be visibly displayed on the manufacturers' freely accessible websites:

a)for each standby and/or off mode and the condition providing networked standby into which the equipment is switched by the power management function or similar function:

- the power consumption data in Watt rounded to the first decimal place,
- the period of time after which the power management function, or a similar function, switches the equipment automatically into standby and/or off mode and/or the condition providing networked standby;

1 the power consumption of another condition: 0.2W

2 Networked standby

Type of Network port	power consumption of Networked standby (W)	Time(min)
WLAN 2.4G	3.4	1
WLAN 5G	3.5	1
WCDMA	3.2	1
LTE	2.7	1
TEL	2.7	1
WAN	2.8	1
LAN	3.0	1

AS of 1 January 2015, the following information for network equipment shall be visibly displayed on the manufacturers' freely accessible websites and user manual:

b) The power consumption of product in networked standby if all wired network ports are connected and all wireless network ports are activated: 4.7 W.

c) Guidance on how to activate and deactivate wireless network ports.

Type of wireless network ports	Guidance
WLAN 2.4G	1. Connect your computer to the router's Wi-Fi network (or connect the computer to the router's LAN port using an Ethernet cable). Open your Internet browser. Enter 192.168.8.1 in your browser address bar and log in to your router's web-based management page. 2. Choose Wi-Fi Settings > Wi-Fi

	Basic Settings. Click the WLAN switch, and choose to enable or disable the 2.4 GHz Wi-Fi.
WLAN 5G	1. Connect your computer to the router's Wi-Fi network (or connect the computer to the router's LAN port using an Ethernet cable). Open your Internet browser. Enter 192.168.8.1 in your browser address bar and log in to your router's web-based management page. 2. Choose Wi-Fi Settings > Wi-Fi Basic Settings. Click the WLAN switch, and choose to enable or disable the 5 GHz Wi-Fi.